

# QUADRA FLEX™ VI 07-819-1

## ROLL-UP SIGN STANDS

### TO UNFOLD

1. Pull inner Telescoping Legs out. Detent Button snaps into hole securing legs in expanded position. (A)
2. Depress the Kick Release Lever on all four legs resting the legs down into the deployed position. Stand is ready to accept the sign. (B)

### TWO POSITION LEGS

#### ALLOW STAND TO BE USED ON UNEVEN TERRAIN

3. To adjust stand for sloping ground, simply depress Kick Release Levers as needed and drop legs into position to level the stand. (C)

### TO ATTACH THE SIGN TO THE STAND

4. Back screw lock out all the way to allow space to accept vertical rib on back of sign. (D)
5. Slide the rib into that space and screw lock back in until it pinches the rib in place - securely. (E)



Sign and stand are ready to deploy in roadway

### TO REMOVE SIGN AND FOLD DOWN STAND SIMPLY REVERSE THE ABOVE STEPS

### IMPORTANT

For maximum safety and stability, legs should be in normal position when unit is on flat terrain.

**WARNING:** For use on streets and highways, the user must comply with all laws and regulations and/or Manual on Uniform Traffic Control Devices and check with local enforcement agency for compliance.



Sign Stand  
Storage Position

Pull inner Telescoping Legs up allowing Detent Button to snap into place.

