



- Remove the yellow Bottom Cover by prying open the skirt (rim) of the Housing
- **D-Cell MODEL**— remove the black battery cover install (4) D-cells in the battery tray, orientation is indicated by the symbols. Replace the battery cover
- **6-Volt MODEL**— install 6-volt lantern batteries- these models will work with 1 or 2 batteries
- Put the yellow Bottom Cover back on the Housing

OPERATION

3-WAY MODEL

FLASHING—Push the Key Pin into the hole in the FRONT of Housing

Steady "ON"— Push the Key Pin gently to find the Middle Position of the Switch

To turn "OFF"— Push the Key Pin into the hole in the BACK of Housing

NOTE

The "FRONT" has the little metal plate at the bottom
The "BACK" has the hole for the Barricade Light Bolt, 1/2" diameter

ALERT

Lights with Photocells turn themselves off in daylight to save battery life.

Setup, testing and checking should be done indoors or in a darkened space.



BARRICADE LIGHTS

Meets all MUTCD and ITE specifications in 12 volt configuration. Reliable chip circuit is weather resistant. 7" polycarbonate lens provides extreme durability. Attaches to all barricades. State of the art optics. UV stabilized polycarbonate. 10 lights, 1 wrench and 10 bolts are included in a package.

MFR. NO.

03-10-3WAY6V
03-10-3WRY6V
03-10-3WAYDC
03-10-3WRYDC
03-10-BLAY6V
03-10-BLRY6V
03-10-BLAYDC
03-10-BLRYDC

PRODUCT DESCRIPTION

BARRICADE LIGHT, 6V W/ PHOTOCCELL
BARRICADE LIGHT, 6V W/ PHOTOCCELL
BARRICADE LIGHT, D-CELL W/PHOTOCCELL
BARRICADE LIGHT, D-CELL W/PHOTOCCELL
BARRICADE LIGHT, 6V, TYPE B LIGHT
BARRICADE LIGHT, 6V, TYPE B LIGHT
BARRICADE LIGHT, D-CELL, TYPE B LIGHT
BARRICADE LIGHT, D-CELL, TYPE B LIGHT

SPECIFICATION

3-WAY SWITCH, YELLOW CASE/AMBER LENS*
3-WAY SWITCH, YELLOW CASE/RED LENS
3-WAY SWITCH, YELLOW CASE/AMBER LENS*
3-WAY SWITCH, YELLOW CASE/RED LENS
YELLOW CASE/AMBER LENS*
YELLOW CASE/RED LENS
YELLOW CASE/AMBER LENS*
YELLOW CASE/RED LENS